Sheet Polarizers SP

Schematic

Mark of polarization axis

Unpolarized bean

--



By the use of dichroic dye film, a good linear polarization can be obtained in a wide range. The sheet polarizer can be used in the basic polarization experiments which does not require the high precision, and for the light intensity adjustment.

- Since the polarizing film is sandwiched between the protective glass plate, its is hardly get scratched, and dirt can be wiped off.
- Because it is mounted in the frame, the handling of the optics and mounting to the holder is easy.
- There are three teepees in wavelength range, for Visible, for UV and for Near Infrared.

Polarization element sandwiched

and then glued into place

Linearly polarized light

Metal frame

• Since the anti-reflection film is applied on both sides, you can reduce stray light and back reflection to the light source.



Specifications			
Material	Dicrhoic dye film Sheet glass (Quartz glass for NSPFU) Film laminated between optical glasses		
Coating	Anti-reflection coating on both surfaces		
Material of metal frame	Aluminum Finishing: Black anodized		

Guide

- ► A sheet polarizer other than the size listed in catalog, or without the frame are also available.
- ▶ If there is a demand in transmittance, extinction ratio and wavelength range, please contact our International Sales Division.
- ► Glan Thompson prism (GTPP) with high transmittance and high extinction ratio are also available. Reference C087

Attention

- ▶ Dichroic dye polarizing film has the amount of light loss due to absorption in addition to polarization characteristics.
- ▶ Because the product is made of a heat-sensitive film, do not use it near high power lasers, or high temperature light source.
- ▶ The extinction ratio varies by wavelength. The violet light may be observed in some extinction condition.
- ▶ The marks on the surface of the frame are perpendicular to the polarization direction of the output linearly polarized beam.

Outline Drawing		(in mm)
Mark of axis direction	6 -9.1 t	●Tolerance Diameter A ^{.0} _{.0.1}

400 – 700nm	400 – 700nm				
Part Number	Wavelength Range [nm]	Diameter of frame A [mm]	Clear aperture D [mm]	Thcikness t [mm]	
SP-30C-32	400 – 700	ϕ 30	φ24	3	
SP-50C-32	400 – 700	φ50	φ44	3	

320 – 400nm	320 – 400nm				
Part Number	Wavelength Range [nm]	Diameter of frame A [mm]	Clear aperture D [mm]	Thcikness t [mm]	
SP-3240-30C	320 – 400	ϕ 30	φ24	2.4	

760 – 2000nm				
Part Number	Wavelength Range [nm]	Diameter of frame A [mm]	Clear aperture D [mm]	Thcikness t [mm]
SP-76200-30C-26	760 – 2000	φ30	φ24	3

Application Systems

Machine Vision

Manual Positions

Motion Control Products

Optical & Mirror Holder

FA Parts

Measurement &Control

FA Electrical Parts

Tool & Measure

Cleanroom & AntiStatic

Index

Mirrors

Beamsplitters

Filters

Polarizers


Lenses

Multi-Element Optics

Prisms

Substrates & Windows

Holder & Vibration isolator



Compatible Optic Mounts